

# The Pool Cooler

***Have a really COOL POOL this summer!***

Is summer heat making your pool too warm? Take control with your own cooling tower.

- Cools while your filtering system is running.
- No extra costs to operate.
- Directional sprayer fits your pool.
- Installs and removes in seconds.\*
- Connects to either in-ground or above ground pools.
- Will not interfere with the swimming area.
- **Kids love it!**



\*Initial Installation under 5 minutes.

\*2 pool coolers shown above

## **Installation Instructions:**

Remove all three fittings (1) Retaining Ring,(2) Eye Ball and (3) Threaded adapter sticking on pool wall currently in the return outlet preferably by Strap wrench or use Wire Stripper round jaws to the notches of wall pool adapter. Screw the threaded adapter into the return outlet. Position the header pipe at the opening of the adapter with the top of the header pipe pointing towards 10 o'clock. While pressing the header pipe into the adapter\*, straighten the pipe to an upright position. Next, insert the sprayer into the top of the header pipe with its holes positioned for the best return of the water into the pool. An extra plug is added to this kit in case more pressure is needed (in-ground only). Do not allow children to swing on **The Pool Cooler**.



## **Removal Instructions:**

While pulling at the bottom bend of the header pipe, move the pipe back towards the 10 o'clock position. **Heavy pressure is not required!** The adapter will remain in the pools return outlet for when future cooling is needed.

## **For Best Results:**

Cycle pools filtration system during the night hours while the air is at its coolest. Install The Pool Cooler at each end of your pool for maximized cooling.

**Do not glue header pipe into adapter.**

**MISTCOOLING INC.**

Richmond, TX USA [www.mistcooling.com](http://www.mistcooling.com)